



## **TX COMBINE**

### **FERTILISER SOWING GUIDE (IMPERIAL)**

<b>STANDARD SUPER</b>												
<b>11 TO 51 SPROCKET</b>												
Cast Gear Selection	Driver	16*	30	32	34							
	Driven	62*	48	46	44							
Rate	lb./acre	13	34	37	43							
<b>11 TO 38 SPROCKET</b>												
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48
	Driven	62*	48	46	44	42	40	38	36	34	32	30
Rate	lb./acre	19	47	51	57	61	67	74	81	91	101	108
<b>19 TO 38 SPROCKET</b>												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		80	86	94	107	128	135	143	162	175	189
<b>38 TO 38 SPROCKET</b>												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		155	172	195	216	234	243	270	280	310	351

<b>GRANULAR SUPER</b>												
<b>11 TO 51 SPROCKET</b>												
Cast Gear Selection	Driver	16*	30	32	34							
	Driven	62*	48	46	44							
Rate	lb./acre	10	26	30	34							
<b>11 TO 38 SPROCKET</b>												
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48
	Driven	62*	48	46	44	42	40	38	36	34	32	30
Rate	lb./acre	15	38	43	47	54	58	65	72	80	90	97
<b>19 TO 38 SPROCKET</b>												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		70	77	85	92	104	112	125	141	151	173

(\*16 and 62 Gears are Optional Extra)

Revision: 1 - 10/01/2025

Excel Agriculture is not responsible for the improper use of this guide. The information is for informational purposes only, and the user assumes full responsibility for its application.



GRANULAR SUPER (CONT.)												
38 TO 38 SPROCKET												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		138	150	165	184	205	216	237	264	286	313

UREA												
11 TO 51 SPROCKET												
Cast Gear Selection	Driver	16*	30	32	34							
	Driven	62*	48	46	44							
Rate	lb./acre	8	20	24	27							
11 TO 38 SPROCKET												
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48
	Driven	62*	48	46	44	42	40	38	36	34	32	30
Rate	lb./acre	12	30	34	37	40	44	49	54	61	69	75
19 TO 38 SPROCKET												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		48	55	62	69	76	86	94	104	118	128
38 TO 38 SPROCKET												
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48
	Driven		48	46	44	42	40	38	36	34	32	30
Rate	lb./acre		101	115	125	140	152	164	182	200	220	243

(\*16 and 62 Gears are Optional Extra)