



TX COMBINE

FERTILISER GUIDE (METRIC)

STANDARD SUPER													
11 TO 51 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34								
	Driven	62*	48	46	44								
Rate	Kg/ha		15	38	41	48							
11 TO 38 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48	
	Driven	62*	48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha		21	53	57	64	68	75	83	91	102	113	121
19 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			90	97	106	120	144	152	161	182	197	212
38 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			174	193	219	243	263	273	303	315	348	394

GRANULAR SUPER													
11 TO 51 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34								
	Driven	62*	48	46	44								
Rate	Kg/ha		11	29	34	38							
11 TO 38 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48	
	Driven	62*	48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha		17	43	48	53	61	65	73	81	91	101	109

* 16 and 62 Gears are Optional Extra



GRANULAR SUPER (CON'T)													
19 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			79	86	95	103	117	123	140	158	170	194
38 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			155	168	185	207	230	243	266	297	321	352

UREA													
11 TO 51 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34								
	Driven	62*	48	46	44								
Rate	Kg/ha		9	22	27	30							
11 TO 38 SPROCKET													
Cast Gear Selection	Driver	16*	30	32	34	36	38	40	42	44	46	48	
	Driven	62*	48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha		13	34	38	41	45	49	55	61	68	77	84
19 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			54	62	70	77	85	97	106	117	132	144
38 TO 38 SPROCKET													
Cast Gear Selection	Driver		30	32	34	36	38	40	42	44	46	48	
	Driven		48	46	44	42	40	38	36	34	32	30	
Rate	Kg/ha			113	129	140	157	171	184	204	225	247	273

16* and 62 Gears are Optional Extra

Conversion Factors:

1 kg / hectare = .89 lbs/acre. Eg. 28 kg/ha = 25 lbs/acre.

1 kg. = 2.20 lbs.

1 ha. = 2.47 acres.